

# strands<sup>®</sup>


-lighting division

## MANUAL

### ALASKA SNOW PLOW LAMP LED

**RED** = HIGH BEAM/HEATING LENS  
**BLACK** = - TO CHASSIS GROUND  
**YELLOW** = LOW BEAM/HEATING LENS  
**GREY** = INDICATOR  
**GREEN** = POSITION LIGHT

Alaska comes with a heating lens that provides maximum visibility in any weather. The feature is automatic, starts at five degrees and keeps snow and ice away from the lens - without any handling by the driver.



#### WARNING!

1. Work under the specified voltage (DC9-32V).
2. This light becomes hot under continuous use. Don't remove or touch the casing for at least 30 minutes after turning the lamp off.
3. Keep heat-sink clean and exposed to maintain air flow.

Part no. 270708

Contact us if you need support: [support@strands.se](mailto:support@strands.se) or +46(0)320-450450



[www.strands.se](http://www.strands.se)  
[www.strandseurope.com](http://www.strandseurope.com)